

Making An Erosion Vase

with Neil Scobie



Select Good timber. Close grain, no defects.

Getting The Shape right.

Think about :-

Golden Mean. 1 to 1.6

Use a Chain.



Turn between Centres



Drill with round end speed bore drill



Turn out inside to 6mm wall thickness



Draw the design on, use a 5b pencil



Rough out the shape with Proxxon or



Pierce the holes with a 3mm diameter



Sand the carved area with a small soft sander.



Sand the holes with strips of cloth abrasive.



Use gouges if you wish to create the carved area.

